# Congratulations on your new FlipBooKit!

### Your FlipBooKit:

- · has been designed with love.
- is made from carefully selected materials & custom made parts.
- is easy to build.

After you construct your FlipBooKit, you can create your own 24 frame animation using our online

### MAKER TOOL @ www.flipbookit.com

You can also find out about the early history of moving pictures in the "about" section of the FlipBooKit site.

# WARNING: CHOKING HAZARD



THIS KIT CONTAINS SMALL PARTS AND SHOULD NOT BE HANDLED BY CHILDREN UNDER 3 YEARS OLD.

# **PARTS:**

Start by unpacking your FlipBooKit and looking through the parts. Here's a list of what you will find:

FlipBooKit Box - folded box Printed Flip Cards - 24 cards

(four die-cut plastic sheets)

9 Snap Rivets - 18 male and female pieces
(8 are used, with one spare pair)

## Spindle Assembly Parts

(Black plastic parts in a bag)

Hex-Hole Disk

Axle Disk

- (2) "H" sections
- (2) Plastic Bushings
- (1) Crank Handle

Axle Pin


# Plastic Flipper & Page-catch

Used as an insert for card restraint

**Tape Square** (in rivet bag)

# www.FlipBooKit.com

FlipBooKit and the FlipBooKit logo are trademarks owned by Wackystuff Inc. © 2012 All Rights Reserved - WackyStuff Inc.




4 Fold in the triangular flaps.



Adjust the folds so the holes line up and the remaining 4 snap-rivets can be installed.


Slots in rivets are decorative. No screwdriver is required.



Locate these two plastic bushings.

Find them in the bag with the black plastic spindle parts.

Insert the **bushings** through the two holes from inside the box.





10 Use same action to attach the hexhole disk to the other side of the interlocking h-sections.

(The hex-hole disk has a thick hub and a thin hub. Make sure the thin hub is facing into the h-sections and the thick hub is facing out.)



Make sure the disks are snapped in place securely. They should not pull apart easily.

Locate the **axle pin** and the **crank-pulley.**Insert the **axle pin** into the crank-pulley (it does not have to be pushed in all the way yet).



crank-pulley

Turn the box on it's side so the notch inside the top flap is on your left side. Insert the **spin-dle's axle** into the bottom bushing.



Use plenty of light for this step. Peer into the top bushing and align the **spindle's hex-hole** with the bushing hole. Insert the free side of the pin into the hex -hole bushing.






14


12

With box still resting on a table, firmly push down on center of the **crank-pulley** until the axle pins are fully engaged. Take it for a spin!

The **spindle** should now rotate when you turn the **crank**.



Locate the plastic **flipper** & **page-catch.** line up holes to pins as shown, and firmly squeeze until they are joined. If you desire a permanently attached page-catch, please see to our website for instructions.



FOR HOUSEHOLDS WITH SMALL CHILDREN, IT IS ADVISABLE TO DISCARD PAGE-CATCH TO REDUCE CHOKING HAZARDS.

16

Apply the sticky tape to flipper's flat surface.


You're now ready to load cards!

Have a look at the numbers on the preprinted **flip-cards**. Remove all cards and arrange them into an ordered deck 1-24. (be gentle when touching the sprockets.)

Set your FlipBooKit on a table so that the box opening is facing up and the crank is on your right side.



Hold the flip-card so that the top is up and the number (1) is facing you. Bow the flip-card between your fingers so that the two sprockets on either.







Once the **flip-card** is in, turn the **crank** a slight bit forward (counter clockwise). Move the **flip-card** down so that you can see its bottom half.

22 Insert flip-card number (2) into the next hole-pair as pictured. Continue until all flip-cards are loaded.



When you have loaded the last frame, you are ready to try out your **FlipBooKit!** 

**17** 

Expose the tape and slide the **flipper's** flat side into the notched recess (*inside the top of the box*).

Pinch the two sides of the box lip to make it permanent.

